

Converting to a Low-water Landscape: A “How-to”



Karrie Reid
Environmental Horticulture Advisor
San Joaquin County


Factors in Landscape Water Use

Features

- Plant choices
- Climate /Microclimate/
Time of Year
- Delivery System

Practices

- Establishment
- Scheduling



Lessons from Irrigation Trials

A photograph of an irrigation trial field. The field is filled with various plants, including clumps of green grasses, purple flowers, and orange flowers. The plants are arranged in rows, and black drip irrigation lines are visible on the ground. The background shows a line of trees under a blue sky with light clouds.

- 1. Plant choice is key to conservation**
- 2. Establishment of deep root system promotes drought tolerance**
- 3. Low and slow delivery is best**
- 4. Mulch makes a difference**

Low-water use vs. Drought-tolerant



Steps to Converting Your Landscape

1. Assess your plants
2. Assess your irrigation
3. Make a plan
4. Change/ fix hardscape
5. Install/convert irrigation to most efficient for the space
6. Plant new material



Assess your plants and trees

- **Remove**
 - high maintenance plants
 - high water users
 - anything you don't like

*Plants aren't children-
it's okay to get rid of them
if they don't
perform!*

- **Build around what you like/looks good**
- **Move plants together with similar water needs**
- *Make a list of plants you'd like and your empty spaces*

Assess your irrigation

- Find your valves- what do they water?
- Which stations on your controller are assigned to each valve?
- Find all sprinkler heads
- Find old drip heads



Converting to In-line Drip

WHERE?

- Shrub beds, borders, hell-strips

WHY?

- Avoid blockage by plants
- Most efficient if installed properly



What is In-line Drip?



- Tubing with internal emitters
- Laid in grid patterns
- Different emitter rates
 - .24, 0.4, 0.6, 0.9 GPH
- Different emitter spacing
 - 12", 18", 24"

Looped (“Lite”) Layout



From the Techline CV Design Guide

Design & Scheduling Specifications

	Clay			Loam			Sandy		
Rate (gph)	0.26			0.4			0.6-0.9		
Emitter spacing (in)	18			18			12		
Row spacing	18	21	24	18	21	24	16	18	20
App. Rate (in/hr)	.19	.16	.14	.3	.26	.23	.7-1.1	.65-1	.6-.9
Minutes to apply ¼ "	80	96	106	50	58	66	13-20	15-23	17-26

Download: Hunter Drip Irrigation Design Guide
Netafim Techline CV Design Guide

What will you need?



What will you need?



For single valve control



- Main valve
- Pressure compensator
- Timer
- Drip adapter

- Elbows

To use existing controller/valves

- Cap unnecessary sprinkler heads/drip distributors
- Unscrew heads from strategically located sprinkler risers
- Add elbow (and pressure regulator)
- Add barbed T-adapter



Check your pressure to see how much line you can run on each head!

Last Steps



- Lay your line according to the guidelines and your space.
- Add a vent at the farthest spot on each line.
- Run the system to flush out any soil.

Helpful Hints with Inline Drip

- Lay your line out in the sun to soften the tubing and prevent kinks.
- Use something hard to push staples in.
- If curves are too sharp, use an elbow.



Helpful Hints with Inline Drip

- Use cross connectors with long runs
- Use concentric rings around trees
- Add loops for rounded beds



Cross-connect long runs/ loops

(can use cross fitting in center)



Adapt your grid to your space



Converting turf areas

- Quit watering/ Glyphosate if impatient
- Scalp what's left
- Cut out edges below concrete grade

Converting turf areas

- Outline beds



Converting turf areas

- Change irrigation



Converting turf areas

- Create beds
- Lay sheet mulch or cloth
- Lay walkway material



Helpful Hint: get one of these




Planting for Success

- **HYDROZONE**
- **Plant in autumn to take advantage of cooler temps and rain**
- **Closely inspect plants in the nursery for**
 - **Pests/disease signs**
 - **Healthy root systems**
- **Buy small except for slow growers**

Hydrozone!

- Group plants on valves by water needs
- Highest water user will always call the shots





Planting for Success

- Hole *NO DEEPER* than root ball
- Hole twice as wide
- Backfill with native soil
- Gouge sides of smooth clay holes
- Final goal: **crown at grade or slightly above**





Image by Jared Sisneroz

Tree Planting

DIG THE HOLE:

- 2-3 x as wide as pot/ball
- Almost as deep as root ball
- **BREAK UP** soil from hole
- Back fill with native soil
- **FIRM** soil around roots
- Make a berm and water well



Proper new tree watering berm



REMOVE AFTER 1 YEAR!

What *not* to do



What *not* to do

Plant too high

Leave soil in large clods

Put chunks of bark in planting hole



Why Mulch?

- **Reduces water-loss to evaporation**
- **Moderates soil temperature reducing root stress & increasing biological activity**
- **Reduces runoff**
- **Increases infiltration by**
 - **Preventing soil crusting**
 - **Improving soil texture over time**
- **NOTE: Sprinklers will need to soak bark to reach soil**

Mulch- side benefits

- Reduces green waste if using own material
- Reduces weeds and makes them easier to manage
- Tidier landscape appearance



Establishing a maximum capacity root system

- Careful watering critical during establishment
- Frequency will vary by
 - Soil type
 - Season
- Creates maximum access to water storage





Before Maturity

- Most plants are ***HIGH WATER USERS***
 - **TREES**— 3-5 years of regular water
 - **SHRUBS** – 1 full year of regular water
 - **PERENNIALS** – 1 year or 1 spring & summer (for spring or summer planting)

RULE OF THUMB

New plantings - *frequent water* until roots have grown into surrounding soil

- **SUMMER** – every 2 or 3 days
- **SPRING/FALL** – 1X/wk (depending on rainfall)

Establishing a maximum capacity root system

- Irrigation should begin at the pot/soil margin
- Gradually add water further out
- Drive roots down: water should go below the root ball




Copyright © The Regents of the University of California. All Rights Reserved.

Establishing a maximum capacity root system




- Each season the irrigation intervals increase
- Allow some dry-down between intervals
- Eliminate tree water between trunk and drip-line ½-way mark

Root Zone of Trees



Effective Irrigation

- Get it to the root zone- low and slow
- Check with a soil probe for adequate depth: 12-18"
- When developing schedules - check for dry-down before irrigation



Landscape Factors

- **Plant materials**
- **Planting density: higher density = more water**
- **Plant maturity**





Questions?