




Sprinkler precipitation rates – the key to controlling irrigation runoff and deep percolation

Spray nozzles have a high precipitation rate that frequently results in irrigation runoff. The precipitation rate will vary with pressure and spacing. At 30 psi and spaced in a square pattern the precipitation rate is 1.58" per hour. The triangular pattern has slightly higher precipitation rates due to the tighter row spacing of 13 ft. at 1.83"

15 Series MPR					
30° Trajectory					
Nozzle	Pressure psi	Radius ft.	Flow GPM	Precip In/h	Precip In/h
15F 	15	11	2.60	2.07	2.39
	20	12	3.00	2.01	2.32
	25	14	3.30	1.62	1.87
	30	15	3.70	1.58	1.83
15H 	15	11	1.30	2.07	2.39
	20	12	1.50	2.01	2.32
	25	14	1.65	1.62	1.87
	30	15	1.85	1.58	1.83



Verify the working water pressure at the spray nozzle to be a minimum of 30 psi. In the case of the 15 Series nozzle, any pressure less than 30 psi requires a closer spacing than 15 ft. If the sprinklers are operating at 20 - 25 psi and spaced at 15 ft there will be serious coverage (uniformity) problems. Measure water pressure as the circuit operates at the first and last sprinkler on the circuit. Verify spacing to be no greater than the radius. Sprinklers should be spaced in a square or triangular pattern with consistent spacing between heads.



Test working water pressure at the first and last sprinkler with a pressure tee and gauge.




Verify spacing between heads with a tape measure. At 30 psi spray heads should be spaced at no greater than their series, i.e 15 series at 15 ft, 12 series at 12 ft, etc.

Rotor sprinklers rotate a single or multiple streams to achieve coverage. In general, the end of the stream from one sprinkler should hit right at the base of the adjacent sprinkler. The pressure requirement at the nozzle is dependent on the spacing and the nozzle installed in the sprinkler. Performance charts indicate a radius(spacing interval) that can be achieved with a particular nozzle at varying pressures. Generally, these sprinklers have a higher pressure requirement than spray nozzles. As a consequence low nozzle pressure is a common problem. Pressure, along with spacing must be verified in the field. Precipitation rate data may only be relied upon when pressure, nozzle, and spacing agree with nozzle performance data. These sprinklers have lower precipitation rates than sprays and therefore can be run for longer periods before runoff occurs.


PGP Red Standard Nozzle Performance Data					
Nozzle	Pressure PSI	Radius ft.	Flow GPM	Precip in/hr	
				■	▲
1	30	28'	0.5	0.12	0.14
	40	29'	0.6	0.14	0.16
	50	29'	0.7	0.16	0.19
	60	30'	0.8	0.17	0.20
2	30	29'	0.7	0.16	0.19
	40	30'	0.8	0.17	0.20
	50	30'	0.9	0.19	0.22
	60	31'	1.0	0.20	0.23
3	30	30'	0.9	0.19	0.22
	40	31'	1.0	0.20	0.23
	50	31'	1.2	0.24	0.28
	60	32'	1.3	0.24	0.28
4	30	32'	1.2	0.23	0.26
	40	33'	1.4	0.25	0.29
	50	34'	1.6	0.27	0.31
	60	34'	1.8	0.30	0.35
5	30	34'	1.6	0.27	0.31
	40	36'	1.8	0.27	0.31
	50	38'	2.0	0.27	0.31
	60	38'	2.2	0.29	0.34
6	30	34'	2.0	0.33	0.38
	40	36'	2.4	0.36	0.41
	50	38'	2.7	0.36	0.42
	60	38'	2.9	0.39	0.45

These charts represent precipitation rates at half circle or 180 degree setting. For full circle operation divide the chart values by 2!

38 ft. square spacing



#5 noz. - 2.0 gpm @ 50 psi at 360 deg
precipitation rate = 0.135" / hr



#5 noz - 2.0 gpm @50 psi at 180 deg (half circle)
precipitation rate = 0.27" / hr.



The pitot tube and pressure gauge are used to measure nozzle pressure which is evaluated against nozzle performance charts

**Suggested maximum run times on clay soil before runoff occurs
(on flat surfaces)**

infiltration rate - 0.10" / hr

spray	spray	spray	rotors	rotors	rotors	rotors	rotor
1.6" / hr	1.8" / hr	2" / hr	0.25"/hr	0.35" / hr	0.45"/hr	0.55"/hr	0.65"/hr
4 min	4 min	4 min	24 min	17 min	13 min	11 min	9 min

**Suggested maximum run times on clay loam soil before runoff occurs
(on flat surfaces)**

infiltration rate - 0.16" / hr

spray	spray	spray	rotors	rotors	rotors	rotors	rotor
1.6" / hr	1.8" / hr	2" / hr	0.25"/hr	0.35" / hr	0.45"/hr	0.55"/hr	0.65"/hr
6 min	5 min	4 min	38 min	27 min	21 min	17 min	14 min

While most regions of California may be characterized as having soils with a high clay content, the immediate vicinity of Truckee is unique. The USGS soil survey of the 2,500 acres in the environs reveals soils with a coarse texture with low potential for runoff. The top horizons of native soil, where most turfgrass roots are present, range from sandy loam to cobbly sandy loam. Two soil characteristics are quite important when managing irrigation in these soils. Intake/Infiltration rates define the rate at which water will move into the soil. We use this information to determine maximum irrigation run times before runoff occurs on a flat surface. The intake rate for sandy loam ranges from 0.80 to 1.20 inches per hour. Runoff on flat surfaces with this soil type is generally not a problem. A spray head system with a precipitation rate of 1.6" per hour would have to run 30 minutes before runoff would occur.

Predominant Soil Texture classes in the top soil horizon – (Source USGS soil survey – Truckee, CA)

	Complex Description	Slope	Acreage	% of Survey		Horizon 1 - Soil Texture Class	Depth
SIE	Sierraville-Trojan-Kyburz complex	2 to 30 percent slopes	320.4	14.90%	0.152	stony sandy loam	0-9
MEB	Martis-Euer variant complex	2 to 5 percent slopes	387.8	18.00%	0.185	sandy loam	0-17
FUE	Kyburz-Trojan complex	9 to 30 percent slopes	362.4	16.80%	0.172	gravelly sandy loam	0-6
EWB	EWB Inville-Riverwash-Aquolls complex	2 to 5 percent slopes	376.4	17.50%	0.179	cobbly coarse sandy loa	0-10
				67.20%			


The problem with these soils is the waste of water that will occur when water moves past the root zone due to deep percolation. This unseen problem can create pollution to our water sources in different ways than surface runoff. Since the major source of water in Truckee is from the aquifer, there is a potential for contamination due to deep percolation. Furthermore, there is a potential to carry this potentially contaminated water into Tahoe and Donner Lakes.

Water in the root zone profile of the turfgrass must be carefully managed to avoid this problem. At field capacity (when the root zone is charged with water) sandy loam soils have an available water of 0.11 inches of water per inch of soil. Turfgrass with an average root zone depth of 6 inches would have a plant available water of 0.66". This is derived from the formula $PAW = AW \times RZ$ ($0.66" = 0.11 \times 6$). Soils with a higher content of gravel or cobble would have still lower levels of PAW.

Allowable depletion or AD defines the amount of water that can be extracted from the root zone before the plant goes into temporary wilt. The generally accepted approach is to never deplete the soil moisture in the profile more than 50%. Therefore, the maximum amount of water that can be depleted is 0.33" before irrigation must occur. Consequently, the thresholds for maximum run time, is based on a maximum application of 0.33" of water.

Suggested maximum run times on sandy loam soil before deep percolation occurs (maximum application is 0.33" of water)						
type	spray	spray	spray	rotors	rotors	rotors
pr. Rate	2	1.8	1.6	0.65	0.55	0.45
min. run	10	11	12	30	36	44
type	drip		drip l/s	drip l/s	drip	drip
	micro-spray		0.9	0.6	p/source	p/source
			12" x 12"	12" x 12"		
pr. Rate	2.5		1.42	1	0.5	0.25
min. run	8		14	20	40	79

Low head drainage occurs in lateral sprinkler piping after the irrigation valve has shut down. When heavy clay soils are being irrigated, multiple cycles (usually 6-8) must occur every day that irrigation takes place. This necessary cycling process introduces the problem of low head drainage. This problem may be resolved with addition of check valves which may be retrofitted into the base of spray head bodies.



It is not unusual to find irrigation valves with spray and rotor type sprinklers plumbed together. This is never acceptable and should be corrected because of the different precipitation rates of the two types!



While low pressure at spray nozzles is frequently encountered, it is not unusual to find spray systems with excessive pressure. When pressure exceeds 45 psi, the sprinkler body should have a pressure regulating feature. This feature, like the anti-drain check valve, may be retrofitted into an existing spray body without digging up the sprinkler. When sprinkler inlet pressures exceed 75 psi a regulator must be installed at the valve or backflow prevention device location.



Spray heads operating at 90 psi. This problem was corrected with the addition of a regulator feature on the valve.



Internal pressure regulating device is designed for inlet pressures between 45 and 75 psi



Same circuit operating at 30 psi!


Managing the Irrigation Controller in a Drought

The amount of irrigation water applied to the landscape varies with the type of plant material and the precipitation rate of the sprinklers. The environmental factors that drive plant water use are temperature, wind, solar radiation, humidity, and ground temperature and collectively they generate a number known as Evapotranspiration (ET). These factors are nearly impossible for the landscape manager to evaluate in the field. The State of California manages a network of computerized weather stations linked to a free website in a program known as CIMIS (California Irrigation Management Information System). There are nearly 200 of these stations throughout the state. They provide the landscape manager with a number that represents the inches of water plants generally need in a month, week, or day. The number available from the local weather station is known as ET_o or reference ET. There are many regions of the state that lack a local weather station. In these instances tables are available providing monthly averages in the Water Efficient Landscape Ordinance (WELO) which is also available on line.

CIMIS Spatial ET _o - Truckee, CA												
Truckee Spatial ET _o	(inches of water per month)											
	Jan	Feb	Mar	Apr	May	Jun	July	Aug	Sep	Oct	Nov	Dec
WELO average	0.7	0.7	1.7	3.2	4.4	5.4	6.4	5.7	4.1	2.4	0.8	0.6
4 yr average	1.54	1.88	2.92	4.04	5.22	6.3	7.2	6.63	4.93	3.09	1.7	1.16



<http://wwwcimis.water.ca.gov/>



<http://ucanr.edu/sites/WUCOLS/>



Water Efficient Landscape Ordinance (WELO)

<http://www.water.ca.gov/wateruseefficiency/landscapeordinance/>

Every plant has a different water requirement relative to ET_0 based upon the landscape coefficient or K_L . The primary factor that drives that landscape coefficient is the species factor. Our biggest concern in the drought is the water requirement for turfgrass as it consumes the bulk of the landscape water. The plant water requirement ET_L is obtained for any period by multiplying the $ET_0 \times K_L$. In a traditional year cool season turfgrass such as fescue, Kentucky Bluegrass, or rye have a species factor of 70 percent or 0.70. In a drought we reduce this species factor and in turn the landscape coefficient (K_L) to 60 percent or 0.60. This follows guidelines developed by turfgrass experts at the University of California at Davis and Riverside.

July ET_L in a traditional year – ET_0 (7.2") $\times K_L$ (0.70 for cs turf) = 5.04" / month

July ET_L in a drought year – ET_0 (7.2") $\times K_L$ (0.60 for cs turf) = 4.32" / month

The water savings associated with this recommendation will save 0.72" in the peak month of July which is a 14% reduction in water use!

The development of an irrigation schedule is based on the average daily ET_L . In the month of July we have a ET_L of 4.32". The objective is to establish an average daily ET_L which in this case is 0.139" per day ($4.32" / 31 = 0.139"$). The replacement for every 3rd day watering for turf in a typical July is 0.417 inches (3×0.139). Since the AD (allowable depletion) is 0.33" this is not recommended! The only way to achieve this is to amend the soils with organic material or polymers to increase holding capacity. The other alternative is to coax roots to grow more deeply (8-10") to increase holding capacity. So it is suggested that no more than 2 days elapse between watering cycles in sandy loam soils with a 6" turf root zone depth.

As a consequence, and in contradiction of many guidelines, irrigation will have to occur 4 days per week on many sites. The Truckee arear has high ET 's and coarse soils which make scheduling particularly difficult.

Daily ET_L	Sun 0.139"	Mon 0.139"	Tue 0.139"	Wed 0.139"	Thur 0.139"	Fri 0.139"	Sat 0.139"
	Water Sun a.m. replace 0.139"		Water Tue a.m. replace 0.278"		Water Thur a.m. replace 0.278"		Water Sat a.m. replace 0.278"

On Tuesday, Thursday, and Saturday the turf water requirement is 0.278". We have a designated day schedule in this case because of our fixed landscape maintenance schedule on Wednesday. Since we cannot go three days on the turf without creating significant stress and potential dieback, we must water 4 days per week, largely due to the limited holding capacity of clay. As a consequence the Water required on Sunday replaces use on one day (0.139") rather than two (0.278"). Therefore a second program must be utilized for Sunday.

WATERING SCHEDULE FORM EXAMPLE

		PROGRAM A							PROGRAM B							PROGRAM C						
DAY OF THE WEEK		M	T	W	T	F	S	S	M	T	W	T	F	S	S	M	T	W	T	F	S	S
ODD/ EVEN or INTERVAL																						
PROGRAM START TIMES	1	2:00 a.m.							2:00 a.m.													
	2	5:00 a.m.							5:00 a.m.													
	3																					
	4																					
STATION	LOCATION	STATION RUN TIME							STATION RUN TIME							STATION RUN TIME						
1																						
2																						

The next step in scheduling is to determine the run time in minutes required for Tuesday, Thursday, and Saturday. We use a simple run time formula $RT = ET_L$ (turf water requirement) / PR (precipitation rate) x 60 (constant). In this example the sprinkler is a 15 ft spray spaced square at 30 psi with a precipitation rate of 1.58" / hr. Recall the Tuesday ET_L so the run time is as follows ET_L (0.278) / PR (1.58) x 60 = 11 minutes. The problem is that the number is not divisible by 2, but we can have increase run times to make this work. On Program A we'll water 6 minutes per cycle x 2 starts = 12 minutes.



$$RT = \frac{ET_L}{PR} \times 60$$

(plant water requirement) (constant)
(precipitation rate)



WATERING SCHEDULE FORM EXAMPLE

		PROGRAM A							PROGRAM B							PROGRAM C						
DAY OF THE WEEK		M	T	W	T	F	S	S	M	T	W	T	F	S	S	M	T	W	T	F	S	S
ODD/ EVEN or INTERVAL																						
PROGRAM START TIMES	1	2:00 a.m.							2:00 a.m.													
	2	5:00 a.m.							5:00 a.m.													
	3																					
	4																					
STATION	LOCATION	STATION RUN TIME							STATION RUN TIME							STATION RUN TIME						
1		6 minutes																				
2																						

6 minutes x 2 starts = 12 minutes

We've completed the schedule for station 1 for the spray heads on the turf for Tuesday, Thursday, and Saturday. The irrigation water that we had to apply (0.278") requires 2 repeats (to avoid wind and pressure fluctuations) and utilized the capabilities of both the A and B programs. The water requirement for Tuesday, Thursday, and Saturday morning replaces 2 days of turf water use or 0.278 inches of water). We'll use program B, for station 1 on Sunday. The amount of water required on Sunday replaces one day of turf water use or 0.139". The run time for program B (Sunday) is $RT = ET_L / PR \times 60$ ($0.139 / 1.58 \times 60$) = 5 min. It is not possible to divide this into even cycles as 5 minutes is not divisible into equal parts. We will increase time to 6 minutes and have two 3 minute cycles.


WATERING SCHEDULE FORM EXAMPLE

		PROGRAM A							PROGRAM B							PROGRAM C						
DAY OF THE WEEK		M	T	W	T	F	S	S	M	T	W	T	F	S	S	M	T	W	T	F	S	S
ODD/ EVEN or INTERVAL																						
PROGRAM START TIMES	1	2:00 a.m.							2:00 a.m.													
	2	5:00 a.m.							5:00 a.m.													
	3																					
	4																					
STATION	LOCATION	STATION RUN TIME							STATION RUN TIME							STATION RUN TIME						
1		6 minutes							3 minutes													
2																						

3 minutes x 2 starts = 6 minutes

6 minutes x 2 starts = 12 minutes

One important feature of more modern controllers is the percentage or seasonal adjust key or +/- key. It allows adjustment of an entire program by percentages. Heavy clay soils and spray heads render this a meaningless feature. Imagine that there is a 3 minute run time that needs a 10% reduction. The controller times in 1 minute increments so the % key only works for 33% changes (3 minutes reduces to 2 minutes is a 33% change). The only options we have with these short run times is to eliminate a start time or decrease a run time. This is exactly why rotors, with their lower precipitation rates, and longer run times are a better option than sprays. If the rotor station was set for four 10 minute cycles a 90% adjust would reduce the run time to 9 minutes!



Ultimately we need to be very creative in dealing with drought conditions where reduced watering days may be imposed by cities or water agencies. There are many limitations to controller programming when this occurs and they are acutely felt during a drought. Another serious limitation in the more arid regions of the state is the limitation of the water meter to apply water in two days that would normally be applied in 3 to 7 days per week!



Precipitation Rate Tables - Low Volume/Drip-Micro Irrigation Point Source Emitters or Micro Spray

(METER FLOW)

CFM GPM

AREA IN SQUARE FEET(CANOPY AREA)

	50	75	100	125	150	175	200	225	250	275	300	325	350	375	400	425	450	475	500	525	550	575	600	625	650	675	700
0.03 0.25	0.48	0.32	0.24	0.19	0.16	0.14	0.12	0.11	0.10	0.09	0.08																
0.07 0.50	0.96	0.64	0.48	0.39	0.32	0.28	0.24	0.21	0.19	0.18	0.16	0.15	0.14	0.13	0.12	0.11	0.10	0.09	0.08								
0.10 0.75	1.44	0.96	0.72	0.58	0.48	0.41	0.36	0.32	0.29	0.26	0.24	0.22	0.21	0.19	0.18	0.17	0.16	0.15	0.14	0.13	0.12	0.11	0.10	0.09	0.08	0.07	0.06
0.13 1.00	1.93	1.28	0.96	0.77	0.64	0.55	0.48	0.43	0.39	0.35	0.32	0.30	0.28	0.26	0.24	0.23	0.21	0.20	0.19	0.18	0.17	0.16	0.15	0.14	0.13	0.12	0.11
0.17 1.25	2.41	1.61	1.20	0.96	0.80	0.69	0.60	0.54	0.48	0.44	0.40	0.37	0.34	0.32	0.30	0.28	0.27	0.25	0.24	0.23	0.22	0.21	0.20	0.19	0.18	0.17	0.16
0.20 1.50	2.89	1.93	1.44	1.16	0.96	0.83	0.72	0.64	0.58	0.53	0.48	0.44	0.41	0.39	0.36	0.34	0.32	0.30	0.29	0.28	0.26	0.25	0.24	0.23	0.22	0.21	0.20
0.23 1.75	3.37	2.25	1.69	1.35	1.12	0.96	0.84	0.75	0.67	0.61	0.56	0.52	0.48	0.45	0.42	0.40	0.37	0.35	0.34	0.32	0.31	0.29	0.28	0.27	0.26	0.25	0.24
0.27 2.00	3.85	2.57	1.93	1.54	1.28	1.10	0.96	0.86	0.77	0.70	0.64	0.59	0.55	0.51	0.48	0.45	0.43	0.41	0.39	0.37	0.35	0.33	0.32	0.31	0.30	0.29	0.28
0.30 2.25	4.33	2.89	2.17	1.73	1.44	1.24	1.08	0.96	0.87	0.79	0.72	0.67	0.62	0.58	0.54	0.51	0.48	0.46	0.43	0.41	0.39	0.38	0.36	0.35	0.33	0.32	0.31
0.33 2.50	4.82	3.21	2.41	1.93	1.61	1.38	1.20	1.07	0.96	0.88	0.80	0.74	0.69	0.64	0.60	0.57	0.54	0.51	0.48	0.46	0.44	0.42	0.40	0.39	0.37	0.36	0.34
0.37 2.75	5.30	3.53	2.65	2.12	1.77	1.51	1.32	1.18	1.06	0.96	0.88	0.81	0.76	0.71	0.66	0.62	0.59	0.56	0.53	0.50	0.48	0.46	0.44	0.42	0.41	0.39	0.38
0.40 3.00	5.78	3.85	2.89	2.31	1.93	1.65	1.44	1.28	1.16	1.05	0.96	0.89	0.83	0.77	0.72	0.68	0.64	0.61	0.58	0.55	0.53	0.50	0.48	0.46	0.44	0.43	0.41
0.43 3.25	6.26	4.17	3.13	2.50	2.09	1.79	1.56	1.39	1.25	1.14	1.04	0.96	0.89	0.83	0.78	0.74	0.70	0.66	0.63	0.60	0.57	0.54	0.52	0.50	0.48	0.46	0.45
0.47 3.50	6.74	4.49	3.37	2.70	2.25	1.93	1.69	1.50	1.35	1.23	1.12	1.04	0.96	0.90	0.84	0.79	0.75	0.71	0.67	0.64	0.61	0.59	0.56	0.54	0.52	0.50	0.48
0.50 3.75	7.22	4.82	3.61	2.89	2.41	2.06	1.81	1.61	1.44	1.31	1.20	1.11	1.03	0.96	0.90	0.85	0.80	0.76	0.72	0.69	0.66	0.63	0.60	0.58	0.56	0.54	0.52
0.53 4.00	7.70	5.14	3.85	3.08	2.57	2.20	1.93	1.71	1.54	1.40	1.28	1.19	1.10	1.03	0.96	0.91	0.86	0.81	0.77	0.73	0.70	0.67	0.64	0.62	0.59	0.57	0.55
0.57 4.25	8.19	5.46	4.09	3.27	2.73	2.34	2.05	1.82	1.64	1.49	1.36	1.26	1.17	1.09	1.02	0.96	0.91	0.86	0.82	0.78	0.74	0.71	0.68	0.65	0.63	0.61	0.58
0.60 4.50	8.67	5.78	4.33	3.47	2.89	2.48	2.17	1.93	1.73	1.58	1.44	1.33	1.24	1.16	1.08	1.02	0.96	0.91	0.87	0.83	0.79	0.75	0.72	0.69	0.67	0.64	0.62
0.64 4.75	9.15	6.10	4.57	3.66	3.05	2.61	2.29	2.03	1.83	1.66	1.52	1.41	1.31	1.22	1.14	1.08	1.02	0.96	0.91	0.87	0.83	0.80	0.76	0.73	0.70	0.68	0.65
0.67 5.00	9.63	6.42	4.82	3.85	3.21	2.75	2.41	2.14	1.93	1.75	1.61	1.48	1.38	1.28	1.20	1.13	1.07	1.01	0.96	0.92	0.88	0.84	0.80	0.77	0.74	0.71	0.69

* Obtain flow to the area by reading water meter. Calculate canopy area using Ewing's "16 point" measuring system for irregularly shaped areas.



In-Line Drip Tubing Flow Precipitation Rates (Netafim)

GENERAL GUIDELINES	TURF						SHRUB & GROUND COVER					
	CLAY SOIL		LOAM SOIL		SANDY SOIL		CLAY SOIL		LOAM SOIL		SANDY SOIL	
	0.26 GPH	0.4 GPH	0.6 GPH	0.9 GPH	0.26 GPH	0.4 GPH	0.26 GPH	0.4 GPH	0.26 GPH	0.4 GPH	0.26 GPH	0.4 GPH
EMITTER FLOW	18"	20"	22"	18"	20"	22"	18"	20"	22"	18"	20"	22"
EMITTER SPACING	18"	20"	22"	18"	20"	22"	18"	20"	22"	18"	20"	22"
LATERAL (ROW) SPACING	18"	20"	22"	18"	20"	22"	18"	20"	22"	18"	20"	22"
BURIAL DEPTH	Bury evenly throughout the zone from 4" to 6"						On-surface or bury evenly throughout the zone to a maximum of 6"					
APPLICATION RATE (INCHES/HOUR)	0.19	0.17	0.15	0.45	0.41	0.37	0.96	0.83	0.72	1.44	1.24	1.08
TIME TO APPLY 1/4" OF WATER (MINUTES)	81	90	99	33	37	41	16	18	21	10	12	14
Following these maximum spacing guidelines, emitter flow selection can be increased if desired by the designer. 0.9 GPH flow rate available for areas requiring higher infiltration rates, such as coarse sandy soils.												
Note: 0.4, 0.6 and 0.9 GPH are nominal flow rates. Actual flow rates used in the calculations are 0.42, 0.61 and 0.92 GPH.												

Measuring irregularly shaped drip zone canopy

When the geometry of an area is complex, the area can be measured by treating it as a circle. The formula for the area of a circle is $\text{Pi (3.14)} \times \text{radius (squared)} = A$. We can determine the average radius of any shape by measuring the distance from near the center to the perimeter 16 times using a 100 foot tape. We then total these measurements and divide by 16 to obtain the average.

In the field use a fabricated 2 x 2 plywood sheet with a hole in the center for a screwdriver and place this sheet near the approximate center of the area to be measured. Create 16 permanent radii from the center at 22.5 degree increments on the plywood sheet. Use these as a guide and measure to the perimeter.




Figure 1- Measuring an irregularly shaped landscape area

For simplicity of calculation inches are converted to a decimal equivalent. A conversion chart for inches to decimal equivalent may be found on the right side of the table on the reverse side of this page.

This shape has a total of 524.55 feet. The average radius is therefore 32.78 (524.5/16). Find the average radius on the reverse table. We have to interpolate to determine that the area is 3,346 sq. ft

Conversion Chart - Average Radius to Square Feet (16 radii minimum)							
Average Radius (feet)	Area (square feet)	Average Radius (feet)	Area (square feet)	Average Radius (feet)	Area (square feet)	Average Radius (feet)	Area (square feet)
10.00	314	22.00	1,521	43.00	5,809	66.50	13,893
10.25	330	22.50	1,590	43.50	5,945	66.00	13,685
10.50	346	22.75	1,626	44.00	6,082	66.50	13,893
10.75	363	23.00	1,662	44.50	6,221	67.00	14,103
11.00	380	23.25	1,698	45.00	6,362	67.50	14,314
11.25	398	23.50	1,735	45.50	6,504	68.00	14,527
11.50	415	23.75	1,772	46.00	6,648	68.50	14,741
11.75	434	24.00	1,810	46.50	6,793	69.00	14,957
12.00	452	24.25	1,847	47.00	6,940	69.50	15,175
12.25	471	24.50	1,886	47.50	7,088	70.00	15,394
12.50	491	24.75	1,924	48.00	7,238	70.50	15,615
12.75	511	25.00	1,963	48.50	7,390	71.00	15,837
13.00	531	25.50	2,043	49.00	7,543	71.50	16,061
13.25	552	26.00	2,124	49.50	7,698	72.00	16,286
13.50	573	26.50	2,206	50.00	7,854	72.50	16,513
13.75	594	27.00	2,290	50.50	8,012	73.00	16,742
14.00	616	27.50	2,376	51.00	8,171	73.50	16,972
14.25	638	28.00	2,463	51.50	8,332	74.00	17,203
14.50	661	28.50	2,552	52.00	8,495	74.50	17,437
14.75	683	29.00	2,642	52.50	8,659	75.00	17,671
15.00	707	29.50	2,734	53.00	8,825	75.50	17,908
15.25	731	30.00	2,827	53.50	8,992	76.00	18,146
15.50	755	30.50	2,922	54.00	9,161	76.50	18,385
15.75	779	31.00	3,019	54.50	9,331	77.00	18,627
16.00	804	31.50	3,117	55.00	9,503	77.50	18,869
16.25	830	32.00	3,217	55.50	9,677	78.00	19,113
16.50	855	32.50	3,318	56.00	9,852	78.50	19,359
16.75	881	33.00	3,421	56.50	10,029	79.00	19,607
17.00	908	33.50	3,526	57.00	10,207	79.50	19,856
17.25	935	34.00	3,632	57.50	10,387	80.00	20,106
17.50	962	34.50	3,739	58.00	10,568	Decimal Equival.	
18.00	1,018	35.00	3,848	58.50	10,751		
18.25	1,046	35.50	3,959	59.00	10,936	inches	decimal
18.50	1,075	36.00	4,072	59.50	11,122		
18.75	1,104	36.50	4,185	60.00	11,310	1	0.08
19.00	1,134	37.00	4,301	60.50	11,499	2	0.17
19.25	1,164	37.50	4,418	61.00	11,690	3	0.25
19.50	1,195	38.00	4,536	61.50	11,882	4	0.33
19.75	1,225	38.50	4,657	62.00	12,076	5	0.42
20.00	1,257	39.00	4,778	62.50	12,272	6	0.50
20.25	1,288	39.50	4,902	63.00	12,469	7	0.58
20.50	1,320	40.00	5,027	63.50	12,668	8	0.67
20.75	1,353	40.50	5,153	64.00	12,868	9	0.75
21.00	1,385	41.00	5,281	64.50	13,070	10	0.83
21.25	1,419	41.50	5,411	65.00	13,273	11	0.92
21.50	1,452	42.00	5,542	65.50	13,478		
21.75	1,486	42.50	5,675	66.00	13,685		

c. 2009 Ewing Irrigation Products

Once the canopy area of a specific drip irrigation zone has been measured, the flow to the zone must be obtained by operating the zone from the irrigation controller. Proceed to the water meter and observe the flow to the zone as the station is running. Allow a couple of minutes for the tubing to fill and come to full pressure before reading flow at the meter. Proceed to the precipitation rate chart and derive the precipitation rate by matching area in square feet to meter flow in cubic feet per minute (CFM)

Also insure that there is adequate pressure to the last (and or highest) elevation emitter in the zone. Minimum psi for pressure compensating emitters is 10 psi and for drip line 15 psi.

Spray Circuit - Audit Run Time (4 minutes)

<input type="text"/>	psi			Driest 6 catches	
<input type="text"/>	gpm				
<input type="text"/>	cfm				
				Total Avg.	
				(total divided by 6)	
DU _{LQ}	dry 6	<input type="text"/>	psi		<input type="text"/>
	avg of 24	<input type="text"/>	Total of 24 catch readings		<input type="text"/>
DU _{LQ}	<input type="text"/>	PR	= 3.66 x V _{avg}		<input type="text"/>
				t _r x 16.5	PR
				<input type="text"/>	<input type="text"/>

Rotating Stream Circuit - Audit Run Time (10 minutes)

<input type="text"/>	psi			Driest 6 catches	
<input type="text"/>	gpm				
<input type="text"/>	cfm				
				Total Avg.	
				(total divided by 6)	
DU _{LQ}	dry 6	<input type="text"/>	psi		<input type="text"/>
	avg of 24	<input type="text"/>	Total of 24 catch readings		<input type="text"/>
DU _{LQ}	<input type="text"/>	PR	= 3.66 x V _{avg}		<input type="text"/>
				t _r x 16.5	PR
				<input type="text"/>	<input type="text"/>

Estimating Irregularly shaped Areas

Measurement

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

TOTAL
AVG/16
SQ. FT

METER
FLOW
CFM

PR Rate



EMITTER FLOW (TIME TO FILL 2" CAP)

EMITTER TYPE	GPH	FILL TIME
POINT SOURCE	2.00	56 SECONDS
POINT SOURCE	1.00	1 MIN 52 SECONDS
LINE SOURCE	0.92	2 MIN 2 SECONDS
LINE SOURCE	0.61	3 MIN 4 SECONDS
POINT SOURCE	0.50	3 MIN 45 SECONDS
LINE SOURCE	0.42	4 MIN 26 SECONDS

The water meter is an important management tool during the drought. As a landscape professional you can provide a very important service for your customers by monitoring their water use. If you are performing landscape maintenance at a site, then you are visiting it on a weekly basis and it will take just a few minutes to provide this service. Your primary objective in this regard is to look for leaks. Open the valve meter box when you arrive for maintenance and watch the meter for a few moments. There is a low flow indicator on the meter. If the meter is not dedicated to the landscape there may be a flow of potable to the residence or building. Try to check for leaks when no one is present in the building. If the irrigation system is off and no one is home the low flow indicator should not be moving. Observe it for a few seconds to see if it is turning. It may not be turning, but there still may be a leak. Note the position of the needle and the reading on the total flow which looks like a car's odometer. Check this before you leave the site to see if there has been any flow during your maintenance period. Calculate the flow of the leak per hour and multiply by 8,760 (hours per year to determine the amount of water loss per year.



At each maintenance visit check the low flow indicator and the position of the needle and total flow to determine if there is a slow leak. Take a digital image with your phone camera to document any leaks as well as the meter number. This is a great low cost service that you can provide to your customers during the drought!

The water meter is usually located between the curb and the backflow prevention device. Most commercial sites have dedicated landscape meters but this is not always the case. Meters record water volume in gallons or cubic feet, but most water agencies provide meters that record in cubic feet. A cubic foot of water is 7.48 gallons and is a 12"x12"x12" cube. Customers are billed in what is known as ccf's or hundred cubic foot units of 748 gallons.



Each full revolution of the dial on commercial meters (1 ½" and larger) represents a flow of ten cubic feet or 74.8 gallons



Each full revolution of the dial on a residential meter (5/8", 3/4" and 1") represents a flow of one cubic foot or 7.48 gallons

The water meter limits the amount of water that can be delivered to the site. Most irrigation systems were designed with the expectation that they would apply water anywhere from three to seven days per week. Take the system that in non-drought years was able to water six days per week and nine hours per day in the month of July. This is a total watering time of 3,240 minutes (6 x 9 x 60). Let's assume this is a 2" meter providing 50 gallons per minute. Under these conditions the meter could provide up to 162,000 gallons per week. (This 50 gpm flow is an average as some stations such as drip have far less flow and others such as large turf rotors have more)

Now, transition to a drought where watering is allowed two days per week for a maximum of thirty hours per week. The amount of water that could be delivered to the site would be 90,000 gallons (1,800 minutes x 50 = 90,000. Given this shortfall it is likely the site manager will have to set priorities on landscape watering and it is possible that some areas of the landscape may not survive. Invest the landscape water in large trees and shrubs which have the greatest value in the landscape!

APPENDIX

Irrigation Schedule				Truckee, CA													
Pop Up Spray Heads / Cool Season Turf																	
Cool Season Turf with a K_T species factor (maximum stress)					0.60												
<table><tr><td>DU_{LQ}</td><td>0.56</td><td></td></tr><tr><td>PR Rate</td><td>1.58</td><td>inches / hr.</td></tr><tr><td>RTM</td><td>1.36</td><td></td></tr></table>				DU _{LQ}	0.56		PR Rate	1.58	inches / hr.	RTM	1.36		Every other day watering		Every 3rd day watering		
DU _{LQ}	0.56																
PR Rate	1.58	inches / hr.															
RTM	1.36																
	Truckee	Truckee	Truckee	Lower	Upper	Lower	Upper										
	ET ₀	ET ₀	CS Turf	Bndry.	Bndry.	Bndry.	Bndry.										
	Avg	Avg.	Req't	Run Time	Run Time	Run Time	Run Time										
	Monthly	daily	daily	min.	min.	min.	min.										
31	Mar	2.92	0.0942	0.0565	4	6	6	9									
30	Apr	4.04	0.1347	0.0808	6	8	9	13									
31	May	5.22	0.1684	0.1010	8	10	12	16									
30	Jun	6.3	0.2100	0.1260	10	13	14	20									
31	Jul	7.2	0.2323	0.1394	11	14	16	22									
31	Aug	6.63	0.2139	0.1283	10	13	15	20									
30	Sep	4.93	0.1643	0.0986	7	10	11	15									
31	Oct	3.09	0.0997	0.0598	5	6	7	9									
	40.33																
MP Rotators / Cool Season Turf																	
Cool Season Turf with a K_T species factor (maximum stress)					0.60												
<table><tr><td>DU_{LQ}</td><td>0.72</td><td></td></tr><tr><td>PR Rate</td><td>0.43</td><td>inches / hr.</td></tr><tr><td>RTM</td><td>1.2</td><td></td></tr></table>				DU _{LQ}	0.72		PR Rate	0.43	inches / hr.	RTM	1.2		Every other day watering		Every 3rd day watering		caution exceeds Allowable Depletion
DU _{LQ}	0.72																
PR Rate	0.43	inches / hr.															
RTM	1.2																
	Truckee	Truckee	Truckee	Lower	Upper	Lower	Upper										
	ET ₀	ET ₀	CS Turf	Bndry.	Bndry.	Bndry.	Bndry.										
	Avg	Avg.	Req't	Run Time	Run Time	Run Time	Run Time										
	Monthly	daily	daily	min.	min.	min.	min.										
31	Mar	2.92	0.0942	0.0565	16	19	24	28									
30	Apr	4.04	0.1347	0.0808	23	27	34	41									
31	May	5.22	0.1684	0.1010	28	34	42	51									
30	Jun	6.3	0.2100	0.1260	35	42	53	63									
31	Jul	7.2	0.2323	0.1394	39	47	58	70									
31	Aug	6.63	0.2139	0.1283	36	43	54	64									
30	Sep	4.93	0.1643	0.0986	28	33	41	50									
31	Oct	3.09	0.0997	0.0598	17	20	25	30									
MAXIMUM CYCLE LENGTH (IN MINUTES) TO AVOID DEEP PERCOLATION ON SANDY LOAM																	
SPRAYS		10 MINUTES		(15 FT SQUARE SPACING)													
ROTORS		44 MINUTES		(0.43" / HR PRECIP RATE)													
LINE SOURCE DRIP		14 MINUTES		(0.9 GPH - 12" X 12" SPACING)													



Drip / Line Source - 0.9 GPH - 12" x 12" spacing

Ornamental Shrubs with a species factor K_p (max stress) 0.40

DU _{LQ}	0.9	
PR Rate	1.42	inches / hr.
RTM	1.06	

Every other day

Every 3rd day

watering

watering

caution exceeds Allowable Depletion

Truckee

Truckee

Truckee

Lower

Upper

Lower

Upper

ET_o

ET_o

CS Turf

Bndry.

Bndry.

Bndry.

Bndry.

Avg

Avg.

Req't

Run Time

Run Time

Run Time

Run Time

Monthly

daily

daily

min.

min.

min.

min.

31	Mar	2.92	0.0942	0.0377	NA	NA	5	5
30	Apr	4.04	0.1347	0.0539	NA	NA	7	7
31	May	5.22	0.1684	0.0674	NA	NA	9	9
30	Jun	6.3	0.2100	0.0840	NA	NA	11	11
31	Jul	7.2	0.2323	0.0929	NA	NA	12	12
31	Aug	6.63	0.2139	0.0855	NA	NA	11	11
30	Sep	4.93	0.1643	0.0657	NA	NA	8	9
31	Oct	3.09	0.0997	0.0399	NA	NA	5	5

Drip / Point Source - random spacing - 0.25" / hr. PR

Ornamental Shrubs with a species factor K_p (max stress) 0.40

DU _{LQ}	0.9	
PR Rate	0.25	inches / hr.
RTM	1.06	

Every other day

Every 3rd day

watering

watering

Truckee

Truckee

Truckee

Lower

Upper

Lower

Upper

ET_o

ET_o

CS Turf

Bndry.

Bndry.

Bndry.

Bndry.

Avg

Avg.

Req't

Run Time

Run Time

Run Time

Run Time

Monthly

daily

daily

min.

min.

min.

min.

31	Mar	2.92	0.0942	0.0377	NA	NA	27	29
30	Apr	4.04	0.1347	0.0539	NA	NA	39	41
31	May	5.22	0.1684	0.0674	NA	NA	48	51
30	Jun	6.3	0.2100	0.0840	NA	NA	60	64
31	Jul	7.2	0.2323	0.0929	NA	NA	67	71
31	Aug	6.63	0.2139	0.0855	NA	NA	62	65
30	Sep	4.93	0.1643	0.0657	NA	NA	47	50
31	Oct	3.09	0.0997	0.0399	NA	NA	29	30

EWING

2310 S. Curry St
1643 Greg Court

Carson City, NV
Sparks, NV

(775) 884-9530
(775) 355-9530

* lower boundary represents a water time that assumes a high uniformity of application DU_{LQ}

* upper boundary increases run time to account for normal sprinkler uniformity deficiencies

Irrigation Schedule				Reno, NV									
Pop Up Spray Heads / Cool Season Turf													
Cool Season Turf with a K _T species factor (maximum stress)										0.60			
		DU _{LQ}	0.56		Every other day		Every 3rd day						
		PR Rate	1.58	inches / hr.	watering		watering						
		RTM	1.36										
		Reno	Reno	Reno	Lower	Upper		Lower	Upper				
		ET ₀	ET ₀	CS Turf	Bndry.	Bndry.		Bndry.	Bndry.				
		Avg	Avg.	Req't	Run Time	Run Time		Run Time	Run Time				
		Monthly	daily	daily	min.	min.		min.	min.				
31	Mar	4.39	0.1416	0.0850	6	9		10	13				
30	Apr	5.51	0.1837	0.1102	8	11		13	17				
31	May	7.76	0.2503	0.1502	11	16		17	23				
30	Jun	9.21	0.3070	0.1842	14	19		21	29				
31	Jul	10.61	0.3423	0.2054	16	21		23	32				
31	Aug	9.42	0.3039	0.1823	14	19		21	28				
30	Sep	7.18	0.2393	0.1436	11	15		16	22				
31	Oct	4.66	0.1503	0.0902	7	9		10	14				
		58.74											



Drip / Line Source - 0.9 GPH - 12" x 12" spacing

Ornamental Shrubs with a species factor K_p (max stress)

0.40



		DU _{LQ}	0.9		Every other day		Every 3rd day	
		PR Rate	1.42	inches / hr.	watering		watering	
		RTM	1.06					
		Reno	Reno	Reno	Lower	Upper	Lower	Upper
		ET ₀	ET ₀	CS Turf	Bndry.	Bndry.	Bndry.	Bndry.
		Avg	Avg.	Req't	Run Time	Run Time	Run Time	Run Time
		Monthly	daily	daily	min.	min.	min.	min.
31	Mar	4.39	0.1416	0.0566	NA	NA	7	8
30	Apr	5.51	0.1837	0.0735	NA	NA	9	10
31	May	7.76	0.2503	0.1001	NA	NA	13	13
30	Jun	9.21	0.3070	0.1228	NA	NA	16	17
31	Jul	10.61	0.3423	0.1369	NA	NA	17	18
31	Aug	9.42	0.3039	0.1215	NA	NA	15	16
30	Sep	7.18	0.2393	0.0957	NA	NA	12	13
31	Oct	4.66	0.1503	0.0601	NA	NA	8	8



Drip / Point Source - random spacing - 0.25" / hr. PR

Ornamental Shrubs with a species factor K_p (max stress)

0.40

		DU _{LQ}	0.9		Every other day		Every 3rd day	
		PR Rate	0.25	inches / hr.	watering		watering	
		RTM	1.06					
		Reno	Reno	Reno	Lower	Upper	Lower	Upper
		ET ₀	ET ₀	CS Turf	Bndry.	Bndry.	Bndry.	Bndry.
		Avg	Avg.	Req't	Run Time	Run Time	Run Time	Run Time
		Monthly	daily	daily	min.	min.	min.	min.
31	Mar	4.39	0.1416	0.0566	NA	NA	41	43
30	Apr	5.51	0.1837	0.0735	NA	NA	53	56
31	May	7.76	0.2503	0.1001	NA	NA	72	76
30	Jun	9.21	0.3070	0.1228	NA	NA	88	94
31	Jul	10.61	0.3423	0.1369	NA	NA	99	104
31	Aug	9.42	0.3039	0.1215	NA	NA	88	93
30	Sep	7.18	0.2393	0.0957	NA	NA	69	73
31	Oct	4.66	0.1503	0.0601	NA	NA	43	46



EWING

2310 S. Curry St
1643 Greg Court

Carson City, NV
Sparks, NV

(775) 884-9530
(775) 355-9530

* lower boundary represents a water time that assumes a high uniformity of application DU_{LQ}

* upper boundary increases run time to account for normal sprinkler uniformity deficiencies

